

Tube installation instructions

To remove the back panel of the Echelon, remove all of the screws including the screw that is *dead center* at the top of the rear panel.

The tubes for the Echelon are installed from left to right, to install a tube insert the tube to the socket, and then gently rock until the tube base makes contact with the top of the socket.

Here is the installation chart from left to right: We are viewing from the back panel of the echelon with the panel itself removed

5AR4, EL34, EL34, 12ax7m, 12ax7m, 12ax7m.

If you have any questions about the tube installation please call your dealer or Barber electronics.

410-374-5101